



JS1-H JOYSTICK

83147650 [↗](#)

Model code: JS1H-XY-PSH-S-NNN-TPR2-R-Y1A-Y1A-P1A-NNN-Y1A-Y1A-NNN-NNN-NNN-NNN-NNN-+++BRTN-NN

[Where to buy ↗](#)

Product specifications

Characteristic	Value	Description
B: Operational axis	XY	XY: Bi-direct.: X and Y axis
C: Shaft pos. sensing output	PSH	PSH: Standard base w. hall
D: Centering spring	S	S: Standard spring
E: CAN	NNN	NNN: No base or analog base
F1: Mounting	T	T: Top mounting/NBR BOOT
F2: Handle	PR2	PR2: Prof1 v.2 grip
G: Left- or right hand	R	R: Right hand grip
H1: Defining of front plate	Y1A	Y1A: Yellow K12
H2: Defining of front plate	Y1A	Y1A: Yellow K12
H3: Defining of front plate	P1A	P1A: Roller 5mm
H4: Defining of front plate	NNN	NNN: No function
H5: Defining of front plate	Y1A	Y1A: Yellow K12
H6: Defining of front/back	Y1A	Y1A: Yellow K12
H7: Defining of back side	NNN	NNN: No function
H8: Defining of back side	NNN	NNN: No function
H9: Def. of grip front side	NNN	NNN: No function
H10: Def. of grip front side	NNN	NNN: No function
H11: Def. of grip front side	NNN	NNN: No function
H12: Def. of grip side	+++	+++ : JS6000/PROF1 replacement
J1: Grip color	B	B: Black grip & front
J2: Ring	R	R: Red colour band



Characteristic	Value	Description
J3: Connector	T	T: Cable w. SB25 +6pin Deutsch
J4: Kit and ext. Cable	N	N: No ext. Cable or ring
K: Software or settings	NN	NN: No software and settings

General specifications

Characteristic	Value
Proposition 65	Cancer and Reproductive Harm

For the most current information and other product assets, please use this link to visit the product page on Danfoss PowerSource [🔗](#)