



Levers

	Part number	Description
	KIT LPB06	PB06
	KIT LP206	P206
	KIT LP208	P208
	KIT LP506	P506
	KIT LP506-1	P506-x
	KIT LP508	P508
	KIT LP510	P510
	KIT LP606	P606 - PS06
	KIT LP608	P608
	KIT LP808	P808

Levers

	Part number	Description
	KIT LP10A	P10A
	KIT LPLV	PLV
	KIT LP206G	P206G
	KIT LP208G	P208G
	KIT LP506G	P506G
	KIT LP508G	P508G
	KIT L3P510	P510
	KIT LP510G	P510G
	KIT LP608G	P608G
	KIT LP808G	P808G